


NCR Cassette Magnet Configuration Guide


The cassette should be oriented where the handle is on the right and the magnet bar should be on the side facing away from you. You then remove the yellow clips to allow the magnet bar to be removed for configuration.



Type 1 cassette magnet configuration



Type 2 cassette magnet configuration



Type 3 cassette magnet configuration



Type 4 cassette magnet configuration

